

注: 1. 异形槽V高度按工程设计。
2. 承重型可以满足全重3t车辆通过, 也可根据工程设计荷载另行加工。

④ D.JC型	
W	50 75 100 125 150 200 250 300 350 400 450 500
ES	150 175 186 225 250 300 350 400 450 500 550 600
伸缩缝	25 25 25 25 25 25 25 25 25 25 25 25

Material	Aluminum ASTM 6063 T5	DRAWING	钱穆
Thickness	Clear Anodized	CHECKING	刘明祥
Colour		APPROVING	刘云雷
Hardness	ASTM 6063 T5		
		Picture No.	B

Nanjing Meishuo Building Materials Co., Ltd
Expansion Joint

- Clean the garbage and check whether the gap is equally wide and straight.
- Make level
- Make level with high strength of cement mortar. The width is more than 150mm.
- Install the fire barrier. Then snap the ink line on the screed coat to confirm the sidelines of the aluminum base.
- Install the water barrier. The side line of water barrier can't cover the ink line snapped. (Brush the special glue on the surface of the screed coat and the lower surface of the water barrier. After the glue is almost air drying, put water barrier on the screed coat.)

The concrete's surface is usually not straight and equally wide after pouring. The sides of the gap should be mended to be equally wide and straight and has smooth surface.

Plain view

The elevation of the screed coat's top = decorative level - height of aluminum base - thickness of water barrier, and the width of the screed coat is more than 150mm.

注: 1. 异形槽V高度按工程设计。
2. 承重型可以满足全重3t车辆通过, 也可根据工程设计荷载另行加工。

④ D.JC型	
W	50 75 100 125 150 200 250 300 350 400 450 500
ES	150 175 186 225 250 300 350 400 450 500 550 600
伸缩缝	25 25 25 25 25 25 25 25 25 25 25 25

Material	Aluminum ASTM 6063 T5	DRAWING	钱穆
Thickness	Clear Anodized	CHECKING	刘明祥
Colour		APPROVING	刘云雷
Hardness	ASTM 6063 T5		
		Picture No.	B

Nanjing Meishuo Building Materials Co., Ltd
Expansion Joint

- Install the aluminum base.
- Nail the scree to make sure the base on a straight line. Or the aluminum plate can be mismatched when the centering bar bolt is screwed down,
- When you make the decorative level, pls make sure it has the same elevation with the aluminum base. And fill with sealant to make sure the aluminum base and decorative level connect tightly and won't leak.
- Install the centering bar and lean it as 45° with the aluminum base. According to the screw hole of the aluminum plate, confirm the location of the centering bar screw. Make marks on decorative level, place the centering bar as per the mark and place the plate. Fix the screw from one side to the other side.
- Tighten the screw arbor on the plate and finish installation.